
Leica Cyclone 9.1 and Leica CloudWorx

Technical Specifications







REGISTRATION, VISUALISATION, MODELLING & QUERY TOOLS	Cyclone BASIC	REGISTER	REGISTER LT	MODEL	SURVEY	PUBLISHER	IMPORT	Free VIEWER
3D navigation, including 3D mouse support	•	•	•	•	•	•	•	•
Panoramic view mode	•	•	•	•	•	•	•	•
Cloud Level of Detail for fast visualisation	•	•	•	•	•	•	•	•
Model Level of Detail for fast visualisation	•	•	•	•	•	•	•	•
Decimation of point clouds	•	•	•	•	•	,		
Selectable levels of point cloud density	•	•	•	•	•	•	•	•
Quickly show/hide point clouds	•	•	•	•	•	•	•	•
View point clouds with intensity mapping, image color mapping,	\ 	_	•	•	-	•	· ·	<u> </u>
elevation based colour mapping	•	•	•	•	•	•	* *	* *
Gradient Background	•	•	•	•	•	•	•	•
Map external digital photo to point clouds (Texture map)	•	•	•	•	•			
Create Multi-image from cube-mapped images	•	•	•	•	•			
Multi-image blending	•	•	•	•	•	•	•	
View texture mapped colours on point clouds	•	•	•	•	•	+	* *	* *
Limit Box for efficient viewing and interaction of selected regions	•	•	•	•	•	•		* **
Limit Box Manager to organise multiple limit boxes	_							A
,	•	•	•	•	•	•		* *
Quickslice		•		•	•			
Set Limit Box by fence	•	•	•	•	•	•		
Global registration of multiple scans		•	•					
Geo-referencing		•	•					
Cloud-to-cloud registration		•						
Auto Align Scans		•						
SmartAlign for Auto Align		•						
Visual Alignment		•						
Automated registration using HDS targets		•	•					
Automated registration using point clouds		•	•					
Editing Target labels/names	•	•	•					
View scanner locations	•	•	•	•	•	+	•	*
Unify point clouds	•	•	+	•	+		•	
Basic conceptual design & 2D drawing tools				•	•			
Insertion of objects				•				
Replication and editing of objects				•	•			
Planar patch editing		1	ļ					
Make Square or Rectangular	1			•	•			
Create/Fill Hole				•	-			
User-defined quality-of-fit checks		•	•	•	•			
Region growing		•		· ·				
Plane	T	•	1	•	•			
Cylinder				•	•			
,		•		•	_			
Sphere Smooth surface to segment extraneous data	1	•		•	•			
Automated Pipe Run with elbows	+	+		•	+ -			
Virtual Surveyor™ to assign survey feature codes to points				•	•			
Mesh Creation (basis, sampley, TIN)	1	<u> </u>	1		Ι .			
Creation (basic, complex, TIN)		-		•	•			
Intelligent decimation				•	•			
Decimation based on user-specified grid spacing				•	•			
Polyline and breakline support				•	•			
Delete and add faces				•	•			
Fill in holes	1			•	•			
Generate contours from meshes				•	•			
Surface Deviation	1		1		·			
Cut/fill contours				•	•			
Table output on user-specified grid				•	•			
Points on user-specified grid				•	•			
Generate cross-sections through point clouds along an alignment								
Alignment/Station Manager				•	•			
-	1			•	•			
Create Lines at Station					•			

REGISTRATION, VISUALISATION, MODELLING & QUERY TOOLS	Cyclone BASIC	REGISTER	REGISTER LT	MODEL	SURVEY	PUBLISHER	IMPORT	Free VIEWER
Create profiles, plans and sections				•	•			
Import LandXML Alignment				•	•			
Create, Save, @ Load Station Templates				•	•			
Secondary Plan View Window				•	•			
Station Notation display relative to an alignment	•	•	•	•	•	•		*
Fit edge template for curve extraction (e.g. curbs, flowlines)				•	•			
Measure & dimension point clouds and models	1							
Slope distance	•	•	•	•	•			
ΔX, ΔY, ΔZ distances	•	+	•	+	•			
Geometric Object Volume	•			•	•			
Surface area	•			•	•			
Horizontal and Vertical Clearances				•	•			
Angel to Horizontal	•	+	•	•	•			
Angel to Vertical	•	•	•	•	•			
Back angle	•	•	•	•	•			
Cut/fill volume	•			•	•			
Piping takeoff query				•				
Automated visual interference checking				•				
Fit cylinders, structural steel from catalogues				•				
Insert piping components from catalogues (reducer, elbow, branch,								
flange, valve)				•				
Piping Mode to add insulation thickness, Line ID, specification, Symbol Key (SKEY)				•				
Set object creation parameters	•	•	•	•	•			İ
Create and manage object annotation	•	+	•	•	•			
Output feature codes and annotated vertices, spheres, to ASCII	•			•	•			
Generate 2D drawings from 3D models				+	•			
3D redlining	•			+	•			
Scanner simulation	•	+	•	+	•			
Multiple coordinate system support	•	+	•	•	•			
Assign colours & materials to objects	•	+	•	+	•	+		
Create and manage layers	•	+	•	•	•	+		
Save/restore viewpoints	•	+	•	•	•	•		
Save screen image as image file	•	+	•	•	•	+		
Object Grouping				•	•			
Geometry types that can be created:								
HDS flat targets	•	+	•					
HDS spherical targets!	•	+	•					
Black/White targets	•	+	•					
Patch (plane)!		•	•	•				
Extruded patch				•				
Box ^{!†}				•				
Corner!		•		•	•			
Steel shape!†(e.g. I-beam)		•		•				
Cylinder!†		•		٠	•			
Sphere!†		+		•				
Vertex		+	•	+	•			
Line		+		+	•			
Elbow ^{i†} , Reducing Elbow [†]				•				
Cone ^{!†}	İ			•				İ
Torus [†]	İ			•				İ
Reducer (Eccentric, Concentric)†	İ			•				
Flange (Blind, Weld-Neck)†				•				İ
Pipe Tee†								İ
Valve†				•				
Polyline, Polygon				•	•			İ
Rectangle, Square				•	•			İ
	+	+	 			1		
Arc, Circle				*	•			1
Arc, Circle Ellipse				•	•			

REGISTRATION, VISUALISATION, MODELLING & QUERY TOOLS	Cyclone BASIC	REGISTER	REGISTER LT	MODEL	SURVEY	PUBLISHER	IMPORT	Free VIEWER
Point-of-view camera	•			•	•	•		
Point-of-view camera (Height)	•			•	•	•		
Pointed (Ballistic) cone				•	•			
Environmental lighting	•			•	+	•		
Create fly-throughs and output sequence of image files or .AVI (Audio Video Interleave) file				•	•			
Elevation check	•	+	+	•	+			
Pipe Modelling user interface				•				
Auto Black & White Target Extraction		+						
Publish Sitemap and TruView Panoramic File Sets						•		
Ortho Image output	•	•	•	•	•	•		
Estimate normals		•	•	•	•		•	
Scripting				•				
Model Library				•				
Automatic Pipe Finder				•				
Create and QA/QC GeoTags				•	+	•		
Publish GeoTags						•		
Floor Flatness/Floor Levelness				•	•			

[!] These types can be created using best-fit methods.

^{**}No grip editing for size

TruSpace\Keyplan	Cyclone BASIC	REGISTER	REGISTER LT	MODEL	SURVEY	PUBLISHER	IMPORT	Free VIEWER
Open\View KeyPlan	•	•	•	•	•	•		
Create KeyPlan		•	•	•	•	•		
Edit KeyPlan		•	•	•	•	•		
Open TruSpace	•	•	+	•	•			
Extract targets in TruSpace		•	•	•	•			
Measurements in TruSpace	•	•	+	•	•			
View Multi-Image in TruSpace	•	•	+	•	•			
Change Colour Mapping	•	•	+	•	•			
Open ModelSpace view from TruSpace	•	•	+	•	•			
Publish TruView from KeyPlan						•		
Sync view- TruSpace to ModelSpace	•	•	+	•	•			
Quick Limit box from TruSpace to ModelSpace	•	•	+	•	•			
Load Points within Fence	•	•	•	•	•			

DATA IMPORT	Cyclone BASIC	REGISTER	REGISTER LT	MODEL	SURVEY	PUBLISHER	IMPORT	Free VIEWER
ASCII (XYZ, SVY, PTS, PTX, TXT, Customized format)	•	•	•	•	•		•	* *
PTZ, PTG, PTB	•	•	•	•	•		•	* *
Cyclone Object Exchange (COE) format (from AutoCAD, MicroStation, via COE Data Transfer)	•	•	•	•	•		•	* *
SCAN, SC2	•						•	* *
ZFS, ZFC	•	•	+	•	•		•	*
BMP, TIFF, JPEG, PNG	•	•	•	•	•		•	* *
Batch Import and Auto-Align Images (supports iSTAR, Nodal Ninja, Spheron)	•	•	•	•	•	•	•	•
LandXML	•	•	•	•	•		•	*
SIMA	•	•		•	•		•	
Optech: ixf		•					•	
FARO: fls, fws, frp		•					•	
RIEGL: rsp, 3dd		•					•	
LAS	•	•	+	•	•		•	*
Import project data collected on ScanStation C10	+	•	+	•	•		•	*
Import project data collected on ScanStation P15/P16/P20/P30/P40	•	•	•	•	•		•	* *
Import project data collected on Pegasus scanners	•	•	•	•	•		•	*
Import project data collected on BLK360	•	•	•	•	•		•	*
E57	•	•	•	•	•		•	* **
DotProduct: dp	•	•	•	•	+		•	♦ **
HeXML	•	•	+	•	•		•	*
+ Fachiad if liamed and a following in installed an the annual marking								

 $ullet^*$ Enabled if licensed copy of CloudWorx is installed on the same machine

[†] These types can use catalog tables.

^{*}As delivered in database, cannot modify

^{♦**} All CloudWorx except VR

DATA EXPORT	Cyclone BASIC	REGISTER	REGISTER LT	MODEL	SURVEY	PUBLISHER	IMPORT	Free VIEWER
AutoCAD DXF R12	•	•	•	•	•			
Cyclone Object Exchange (COE) format (to AutoCAD, MicroStation via COE Data Transfer)	•	•	•	•	•			
ASCII (XYZ, SVY, PTS, PTX, TXT, Customized format)	•	•	•	•	•			
Binary Point Cloud (PTZ, PTB)**	•	•	•					
PTG	•	•	•					
BMP, TIFF, JPEG, PNG	•	•	•	•	•	+		
Ortho Image, GeoTIFF, TWF (World File)	•	+	•	+	•	+		
Sitemap, TruView						•		
SDNF 3.0 (Intergraph Steel Detailing Neutral File)				•				
PCF (Alias Piping Component File)				•				
Leica System 1200	•			•	•			
LandXML	•			+	•			
Cyclone II TOPO *.cwf & *.pci	•	+	•	+	•	+		+
Automatic 5-day trial license period	•							
CloudWorx-VR *.alp ***	•	+	•	+	•	+		
E57	•	+	•	+	•			
Store in JetStream ProjectVault ****	•	•	•	•	•	•		
*** Enabled if licensed copy of CloudWorx is installed on the sa	me machine	•			•			

**** Enabled if Generator is licensed and configured correctly on JetStream ProjectVault

OTHER GENERAL CYCLONE FEATURES

Metric or imperial units of measure

Decimal Degrees or Degrees, Minutes, Seconds angular units of measure

Bearing unit of measure for Azimuth of Resection

Simultaneous view of video image and scanned data image

Customisable, exchangeable user interface: hotkeys, toolbars

64-bit large number support

64-bit graphics support

Continuous auto-save

Undo/Redo

Client/server object database foundation

Multi-threading to take advantage of multiple processors

Hierarchical project layout

Flexible license support

Terminal Services support

Multi-user profile configuration management

Incremental, intelligent loading of 3D models

Parametric objects

Online help

Leica CloudWorx Technical Specifications

VISUALISATION, MODELLING & QUERY TOOLS	CW AutoCAD Basic 6.2	CW AutoCAD Pro 6.2	CW MicroStation 5.1	CW PDMS 2.1	CW Revit 2.1	CW Navisworks
Large Point Cloud Support	•	•	•	•	•	•
Level of Detail (LOD) graphics	•	•	•	•	•	•
Intensity mapping and True colour	•	•	•	•	•	•
Limit Box Manager	•	•	•	•	•	•
Cutplane Manager (sections, slices)	•	•	•	•	•	•
Hide Regions Manager (fences)	•	•	•	•	•	•
Layers in Cyclone database	•	•	•	•	•	
Tracing	•	•	•	•	•	
Measure: 3D point coordinate	•	•	•	•	•	•
Measure Point-to-point	•	•	•	•	•	•
Measure Point-to-design entity	•	•	•	•	•	•
Limit box	•	•	•	•	•	•
Design Point Placement:						
Pipe Centre D-Point, D-Point at pick				•		
Flange Tie-Point Location Tool:				•	•	
Place flange D-Point from point cloud				<u> </u>	*	
Interference Checking		•	•	•	•	•
Flange Tie-Point Location Tool		•	•		•	
Modelling (Least-Squares fitting)						
Pipes		•	•	•	•	
Planer Patch		•	•		•	
2D lines, Polylines arcs		•	•		•	
Steel Fitter		•	•	•	•	
Advanced clash management database system		•	•		•	•
QuickSlice		•				
Auto-Fit Polyline from 1 Pick & 2 Pick		•				
Open KeyPlan		•	•	•		•
Open TruSpace		•	•	•		•
Sync TruSpace viewer to Viewport or			•	•		
Viewer in CAD system		•	· ·	<u> </u>		v
Sync CAD Drawing tools to TruSpace		•	•			
Quick Limit Box from TruSpace		•	•	•		•
Points On A Grid		•	•			
UCS Orientation Tools		•				
SmartPicks (Highest, Lowest, and Gound)	•	•	•			
Direct import of HeXML	•	•			•	•
Supports JetStream	•	•	•	•	•	•
Connect to Autodesk Recap Point Cloud (RCP)	•	•			•	
JetStream Experience	•	•			•	
Quickslice		•	•			
Auto-Fit Polyline and Arcs		•	•			
Floor Flatness/Floor Levelness		•				
Orthoimage (GeoTIFF, PNG, JPEG)		•				

Leica Geosystems - when it has to be right

Revolutionising the world of measurement and survey for nearly 200 years, Leica Geosystems is the industry leader in measurement and information technologies. We create complete solutions for professionals across the planet. Known for innovative product and solution development, professionals in a diverse mix of industries, such as surveying and engineering, building and heavy construction, safety and security, and power and plant trust Leica Geosystems for all their geospatial needs. With precise and accurate instruments, sophisticated software, and trusted services, Leica Geosystems delivers value every day to those shaping the future of our world.

Leica Geosystems is part of Hexagon (Nasdaq Stockholm: HEXA B; hexagon.com), a leading global provider of information technology solutions that drive productivity and quality across geospatial and industrial landscapes.

Cyrax and HDS are registered trademarks and Cyclone and CloudWorx are trademarks of Leica Geosystems LLC. All other trademarks or registered trademarks are property of their respective

Illustrations, descriptions and technical specifications are not binding and may change. Printed in Switzerland – Copyright Leica Geosystems AG, 2013. 752368en – 04.17

Leica Geosystems AG

leica-geosystems.com









